

# RETRACTABLE GATE

---

READ INSTRUCTIONS THOROUGHLY BEFORE INSTALLING GATE.

## WARNING:

- GATE IS NOT MEANT TO REPLACE PROPER ADULT SUPERVISION.
- THIS GATE IS NOT SUITABLE FOR OPENINGS WIDER THAN 45"
- THE SURFACES THAT THE GATE IS TO BE FIXED TO MUST BE SUITABLE FOR THE PURPOSE AND MUST BE STRUCTURALLY SOUND.
- THIS GATE MUST NEVER BE USED AS A POOL BARRIER.
- THIS ITEM IS NOT DESIGNED TO RESTRAIN AGGRESSIVE PETS.
- IF YOU HAVE ANY DOUBTS ABOUT THE INSTALLATION SEEK THE SERVICES OF A QUALIFIED INSTALLER.

**NOTE:** This item has dual use it can be used to block doorways and hallway openings up to 45" wide.

- Locate the best position for the gate keep in mind the direction the gate will open and close.

**CAUTION:** If the gate is used at the bottom of the stairs, it must be placed on the lowest stair. If the gate is used at the top of the stairs it must not be placed on any stair below the level of the top stair, position the gate 1" away from the first step.

- Overlay the provided template for the gate directly on the wall. You will require tape to hold the template in place. It is recommended for the gate to be installed on a wooden frame stud.
- Overlay the locking bar template directly on the wall on the opposite side of the gate (if the gate is used for blocking a doorway the locking bar will be placed on the door.) You will require tape to hold the template in place.

**NOTE:** The locking bar template will need to be placed 1" higher than the gate so the gate and locking bar evenly match when closed.

- Drill through the center of each hole as marked on the template using a 1/8" drill bit. Drill the two holes for the gate 1.25" deep and the four holes for the locking bar 0.5" deep.
- If the wall is hollow where the gate will be installed drill through both holes with a 1/4" drill bit and insert a wall anchor into both holes. Tap in the wall anchor lightly with a hammer until the anchor is flush with the wall surface. If installing on a wall stud use only the enclosed screw.
- Secure the gate to the wall using the two 1.25" long screws. Do not thread the

screw in all the way, make sure to leave a minimum of 1/16" of the screw unthreaded so the gate can be secured properly.

**NOTE:** If the bottom screw of the gate is installed over the base board, use the provided washers to properly space the gate from the top screw so it is properly evened out.

- Now place the gate onto the screws matching the holes on the gate and slide the gate down to secure it. Adjust the screw as needed to firmly secure the gate.
- Secure the locking bar on the opposite wall(or door) of the gate using the four 0.50" long screw.